

Materials Science

ME 274


Dr Yehia M. Youssef

Chapter 6: Mechanical Properties


ISSUES TO ADDRESS...

- **Stress** and **strain**: What are they and why are they used instead of load and deformation?
- **Elastic** behavior: When loads are small, how much deformation occurs? What materials deform least?
- **Plastic** behavior: At what point does permanent deformation occur? What materials are most resistant to permanent deformation?
- **Toughness** and **ductility**: What are they and how do we measure them?

Elastic Deformation




Plastic Deformation (Metals)



Engineering Stress


- Tensile stress, σ :



$$\sigma = \frac{F_t}{A_o} = \frac{\text{lb}_f}{\text{in}^2} \text{ or } \frac{\text{N}}{\text{m}^2}$$

original area
before loading

- Shear stress, τ :



$$\tau = \frac{F_s}{A_o}$$

∴ Stress has units:
N/m² or lb_f/in²

Common States of Stress

- **Simple tension: cable**




A_0 = cross sectional area (when unloaded)


$$\sigma = \frac{F}{A_0}$$



- **Torsion (a form of shear): drive shaft**



$$\tau = \frac{F_s}{A_0}$$



Note: $\tau = M/A_c R$ here.

Ski lift (photo courtesy P.M. Anderson)

Other Common Stress States (1)

- **Simple compression:**



Balanced Rock, Arches National Park
(photo courtesy P.M. Anderson)



Canyon Bridge, Los Alamos, NM
(photo courtesy P.M. Anderson)

$$\sigma = \frac{F}{A_0}$$




Note: compressive structure member
($\sigma < 0$ here).

Other Common Stress States (2)

- **Bi-axial tension:**




Pressurized tank
(photo courtesy
P.M. Anderson)



- **Hydrostatic compression:**



Fish under water
(photo courtesy
P.M. Anderson)




Engineering Strain

- **Tensile strain:**


$$\epsilon = \frac{\delta}{L_o}$$

- **Lateral strain:**

$$\epsilon_L = \frac{-\delta_L}{w_o}$$



- **Shear strain:**




$$\gamma = \Delta x / y = \tan \theta$$

Strain is always dimensionless.


Adapted from Fig. 6.1 (a) and (c), Callister 7e.

Stress-Strain Testing

- Typical tensile test machine



- Typical tensile specimen





Adapted from Fig. 6.2, Callister 7e.

Adapted from Fig. 6.3, Callister 7e. (Fig. 6.3 is taken from H.W. Hayden, W.G. Moffatt, and J. Wulff, *The Structure and Properties of Materials*, Vol. III, *Mechanical Behavior*, p. 2, John Wiley and Sons, New York, 1965.)

Linear Elastic Properties

- **Modulus of Elasticity, E :**
(also known as Young's modulus)
- **Hooke's Law:**

$$\sigma = E \varepsilon$$



Poisson's ratio, ν


- **Poisson's ratio, ν :**

$$\nu = -\frac{\epsilon_L}{\epsilon}$$

metals: $\nu \sim 0.33$

ceramics: $\nu \sim 0.25$

polymers: $\nu \sim 0.40$



Units:

E : [GPa] or [psi]


ν : dimensionless

$-\nu > 0.50$ density increases

$-\nu < 0.50$ density decreases
(voids form)

Mechanical Properties

- Slope of stress strain plot (which is proportional to the elastic modulus) depends on bond strength of metal





Adapted from Fig. 6.7,
Callister 7e.

Other Elastic Properties



- **Elastic Shear modulus, G :**

$$\tau = G \gamma$$



- **Elastic Bulk modulus, K :**

$$P = -K \frac{\Delta V}{V_0}$$




- **Special relations for isotropic materials:**

$$G = \frac{E}{2(1+\nu)}$$

$$K = \frac{E}{3(1-2\nu)}$$

Young's Moduli: Comparison



Based on data in Table B2, *Callister 7e*.


Composite data based on reinforced epoxy with 60 vol% of aligned carbon (CFRE), aramid (AFRE), or glass (GFRE) fibers.

Useful Linear Elastic Relationships

- Simple tension:


$$\delta = \frac{FL_o}{EA_o}$$

$$\delta_L = -\nu \frac{FW_o}{EA_o}$$



- Simple torsion:

$$\alpha = \frac{2ML_o}{\pi r_o^4 G}$$




- Material, geometric, and loading parameters all contribute to deflection.
- Larger elastic moduli minimize elastic deflection.

Plastic (Permanent) Deformation

(at lower temperatures, i.e. $T < T_{melt}/3$)


- Simple tension test:



Adapted from Fig. 6.10 (a),
Callister 7e.

Yield Strength, σ_y

- Stress at which **noticeable** plastic deformation has occurred.



when $\epsilon_p = 0.002$

$\sigma_y = \text{yield strength}$


Note: for 2 inch sample

$$\epsilon = 0.002 = \Delta z/z$$

$$\therefore \Delta z = 0.004 \text{ in}$$


Adapted from Fig. 6.10 (a),
Callister 7e.

Yield Strength : Comparison




Tensile Strength, TS

- Maximum stress on engineering stress-strain curve.



- **Metals:** occurs when noticeable **necking** starts.
- **Polymers:** occurs when **polymer backbone chains** are aligned and about to break.

Tensile Strength : Comparison



Room Temp. values


Based on data in Table B4,
Callister 7e.

a = annealed
 hr = hot rolled
 ag = aged
 cd = cold drawn
 cw = cold worked
 qt = quenched & tempered
 AFRE, GFRE, & CFRE =
 aramid, glass, & carbon
 fiber-reinforced epoxy
 composites, with 60 vol%
 fibers.

Ductility

- Plastic tensile strain at failure:

$$\%EL = \frac{L_f - L_o}{L_o} \times 100$$




- Another ductility measure:

$$\%RA = \frac{A_o - A_f}{A_o} \times 100$$

Toughness

- Energy to break a unit volume of material
- Approximate by the area under the stress-strain curve.




Brittle fracture: elastic energy

Ductile fracture: elastic + plastic energy

Resilience, U_r

- Ability of a material to store energy
 - Energy stored best in elastic region




$$U_r = \int_0^{\epsilon_y} \sigma d\epsilon$$

If we assume a linear stress-strain curve this simplifies to

$$U_r \cong \frac{1}{2} \sigma_y \epsilon_y$$

Adapted from Fig. 6.15,
Callister 7e.


Elastic Strain Recovery



Adapted from Fig. 6.17,
Callister 7e.

Hardness

- Resistance to permanently indenting the surface.
- Large hardness means:
 - resistance to plastic deformation or cracking in compression.
 - better wear properties.



Hardness: Measurement

- **Rockwell**

- No major sample damage
- Each scale runs to 130 but only useful in range 20-100.
- Minor load 10 kg
- Major load 60 (A), 100 (B) & 150 (C) kg
 - A = diamond, B = 1/16 in. ball, C = diamond











- **HB = Brinell Hardness**

- $TS \text{ (psia)} = 500 \times HB$
- $TS \text{ (MPa)} = 3.45 \times HB$

Hardness: Measurement

Hardness Testing Techniques

Table 6.5

| Test | Indenter | Shape of Indentation | | Load | Formula for Hardness Number ^a |
|-----------------------------------|--|---|---|--|---|
| | | Side View | Top View | | |
| Brinell | 10-mm sphere of steel or tungsten carbide |  |  | P | $HB = \frac{2P}{\pi D[D - \sqrt{D^2 - d^2}]}$ |
| Vickers microhardness | Diamond pyramid |  |  | P | $HV = 1.854P/d_1^2$ |
| Knoop microhardness | Diamond pyramid |  |  | P | $HK = 14.2P/l^2$ |
| Rockwell and Superficial Rockwell | <ul style="list-style-type: none"> ⎧ Diamond cone ⎧ 1/16, 1/8, 1/4, 1/2 in. diameter steel spheres |   |   | <ul style="list-style-type: none"> 60 kg 100 kg 150 kg } Rockwell <ul style="list-style-type: none"> 15 kg 30 kg 45 kg } Superficial Rockwell | |

^a For the hardness formulas given, P (the applied load) is in kg, while D , d , d_1 , and l are all in mm.


Source: Adapted from H. W. Hayden, W. G. Moffatt, and J. Wulff, *The Structure and Properties of Materials*, Vol. III, *Mechanical Behavior*. Copyright © 1965 by John Wiley & Sons, New York. Reprinted by permission of John Wiley & Sons, Inc.

True Stress & Strain

Note: S.A. changes when sample stretched

- True stress $\sigma_T = F/A_i$
- True Strain $\epsilon_T = \ln(l_i/l_o)$


$$\sigma_T = \sigma(1 + \epsilon)$$
$$\epsilon_T = \ln(1 + \epsilon)$$



Adapted from Fig. 6.16,
Callister 7e.

Hardening

- An increase in σ_y due to plastic deformation.



- Curve fit to the stress-strain response:

$$\sigma_T = K(\epsilon_T)^n$$

“true” stress (F/A)

“true” strain: $\ln(L/L_0)$

hardening exponent:
 $n = 0.15$ (some steels)
to $n = 0.5$ (some coppers)

Variability in Material Properties

- Elastic modulus is material property
- Critical properties depend largely on sample flaws (defects, etc.). Large sample to sample variability.
- Statistics

– Mean

$$\bar{x} = \frac{\sum^n x_n}{n}$$

– Standard Deviation

$$s = \left[\frac{\sum^n (x_i - \bar{x})^2}{n-1} \right]^{\frac{1}{2}}$$

where n is the number of data points

Design or Safety Factors

- Design uncertainties mean we do not push the limit.
- Factor of safety, N

$$\sigma_{working} = \frac{\sigma_y}{N}$$

Often N is between 1.2 and 4

- Example: Calculate a diameter, d , to ensure that yield does not occur in the 1045 carbon steel rod below. Use a factor of safety of 5.


$\sigma_{working} = \frac{\sigma_y}{N}$

$\frac{220,000N}{\pi(d^2 / 4)}$

5

$d = 0.067 \text{ m} = 6.7 \text{ cm}$

1045 plain carbon steel:
 $\sigma_y = 310 \text{ MPa}$
 $TS = 565 \text{ MPa}$



$F = 220,000N$

Summary

- **Stress** and **strain**: These are size-independent measures of load and displacement, respectively.
- **Elastic** behavior: This reversible behavior often shows a linear relation between stress and strain. To minimize deformation, select a material with a large elastic modulus (E or G).
- **Plastic** behavior: This permanent deformation behavior occurs when the tensile (or compressive) uniaxial stress reaches σ_y .
- **Toughness**: The energy needed to break a unit volume of material.
- **Ductility**: The plastic strain at failure.